



BEDDING-IN PROCEDURE

In order to achieve optimum performance from your CL Brake Pads, we recommend the following steps to align the friction surfaces and to bring the brake system components to operating temperature.

1. Accelerate the car to around 70-80 km/h
2. Perform about 25 medium pressure braking operations down to around 20-30 km/h.
3. You should feel pedal performance and efficiency increase as the surfaces mate to each other.
4. Then leave the car so that the braking system cools completely.

If you are using new discs this may take longer, please consult with disc manufacturer's instructions.

COMPOUNDS AVAILABLE

