



ENGINE MAP UPLOAD with USB Data Stick

Procedure

- 1. Unzip the zip file received, you should get a file name like this: SRG_update_snXXX . bin (XXX = ECU number)
- 2. Copy the file .bin in the root of the USB key referenced 3Z9S25574A.
- 3. Engine OFF, main switch ON, wait the dashboard to initialize
- 4. Connect the USB key and wait for 1min
- 5. Main switch OFF
- 6. Remove the map file from the USB key to avoid update each time you connect the key to the car
- 7. Do a learning procedure

Information

- The map you get is linked to the serial number of the SRG ECU
- Do not modify the name of the map file ***.bin
- The files SRG_update_snXXX.bin have the same names for each fuel maps. So be careful to keep the .zip file that will allow you to see the different fuels.
- The only way (without sysma) to know if the map has been correctly uploaded is to start engine (to register data) and to send us the RFD_Data file contained in the USB Data Stick afterward.

