


PCRS

Gonesse, le 01/12/2020.


INFO-TECH CITROËN Racing C3R5 20-15**Sujet: Powerbox**

Afin d'améliorer la fiabilité de votre C3R5 et plus particulièrement celle de la powerbox, nous vous recommandons de réaliser un joint de silicone ou CAF entre les 2 parties du boîtier comme illustré sur les photos suivantes :

- Retirer les 6 vis torx,



- Réaliser un joint silicone sur tout le pourtour du châssis,



L'équipe du support technique,


Damien Arbonnier
damien.arbonnier@mpsa.com
 Mobile : +33 6 74 56 77 86

Yann Chalmeton
yann.chalmeton@mpsa.com
 Mobile : +33 6 31 83 00 89


Subject:

In order to improve the reliability of your C3R5 and more precisely of the powerbox, we advise you to add a silicone seal between the 2 parts of the housing as described below:

- Remove the 6 screws,



- Add a silicone seal all around the chassis to ensure proofness,



The technical support team,

Damien Arbonnier
damien.arbonnier@mpsa.com
Mobile : +33 6 74 56 77 86

Yann Chalmeton
yann.chalmeton@mpsa.com
Mobile : +33 6 31 83 00 89